



- Note 1: Data & status may change in response to S2.
- Note 2: During some operations Q may change at any time.
- Note 3: LAM status may be reset during operation.
- Note 4: L signal may be maintained during operation.

Fig. 2.16.
Timing of a dataway command operation.