

Technical Information Manual

**Revision n.0
17 January 1996**

**MOD. C117 B
HS CAENET CAMAC
CRATE CONTROLLER
MANUAL REV. 0**

CAEN will repair or replace any product within the guarantee period if the Guarantor declares that the product is defective due to workmanship or materials and has not been caused by mishandling, negligence on behalf of the User, accident or any abnormal conditions or operations.

CAEN declines all responsibility for damages or injuries caused by an improper use of the Modules due to negligence on behalf of the User. It is strongly recommended to read thoroughly the CAEN User's Manual before any kind of operation.



CAEN reserves the right to change partially or entirely the contents of this Manual at any time and without giving any notice.

Disposal of the Product

The product must never be dumped in the Municipal Waste. Please check your local regulations for disposal of electronics products.




TABLE OF CONTENTS

TABLE OF CONTENTS	i
LIST OF FIGURES	i
LIST OF TABLES.....	ii
1. DESCRIPTION	1
1.1. FUNCTIONAL DESCRIPTION	1
2. SPECIFICATIONS.....	3
2.1. PACKAGING.....	3
2.2. EXTERNAL COMPONENTS.....	3
2.3. POWER REQUIREMENTS	3
3. OPERATING MODES.....	5
3.1. H.S. CAENET NETWORK OPERATION.....	5
3.2. H.S. CAENET NODE OPERATION.....	6
3.3. THE MOD. C117B H.S. CAENET CAMAC CONTROLLER	6
3.4. MOD C117B OPERATING MODES	7
3.4.1. MOD C117B RESET	7
3.4.2. DATA PACKET STORAGE	7
3.4.3. START TRANSMISSION.....	8
3.4.4. WAITING FOR THE SLAVE RESPONSE.....	8
3.4.5. READING THE RESPONSE	9
3.4.6. ENABLE/DISABLE LAM GENERATION	9
3.5. C117B-SLAVE COMMUNICATION SEQUENCE	10
4. CAMAC FUNCTIONS	11
4.1. F(16) N FUNCTION (Write Transmit Data Buffer).....	12
4.2. F(0) N FUNCTION (Read Receive Data Buffer).....	12
4.3. F(17) N FUNCTION (Start Transmission)	13
4.4. F(8) N (Test LAM Line).....	13
4.5. F(9) N, C, Z (Reset Module)	13
4.6. F(24) N (Disable the LAM Generation).....	14
4.7. F(26) N (Enable the LAM Generation)	14
5. C.A.E.N. COMMUNICATION PROTOCOL	15
5.1. H.S. CAENET NETWORK FOR REMOTING CONTROL	15
5.2. H.S. CAENET NETWORK IMPLEMENTATION: CAEN APPROACH	15
5.3. MASTER TO SLAVE DATA COMPOSITION	16
5.4. SLAVE TO MASTER DATA COMPOSITION	17
5.5. ERROR CODES DESCRIPTION	17
APPENDIX A: SOFTWARE BUGS AS OF SEPT. 1992	A.1
APPENDIX B: ELECTRICAL DIAGRAMS	B.1
APPENDIX C: COMPONENT LIST AND LOCATIONS	C.1

LIST OF FIGURES

Fig. 1.1: Mod. C117B Block Diagram.....	2
Fig. 2.1: Mod. C117B Front Panel	4

LIST OF TABLES

Table 4.1: Mod. C117B CAMAC Functions.....	11
Table 5.1: MASTER to SLAVE Data Composition	16
Table 5.2: SLAVE to MASTER Data Composition	17
Table 5.3: Error Codes	17



1. DESCRIPTION

1.1. FUNCTIONAL DESCRIPTION

The Model C117B HIGH SPEED (H.S.) CAENET CAMAC CONTROLLER has been designed to control an H.S. CAENET network through the CAMAC bus. It houses an H.S. CAENET Node and a Control Logic (microprocessor based) which integrates the functions of Node controller and Network error handler.

Standard CAMAC functions allow the User to easily control the serial communication on the H. S. CAENET network according to the typical MASTER/SLAVE communication protocol, where the CAMAC Crate Controller assumes the MASTER function.

It is composed of a collection of registers for the operation control, and two memory buffers for the transmitted and received data packets, arranged in a 16 bit FIFO 256 words deep.

When the H.S. CAENET operation fails, the on-board Control logic generates error messages that are stored in the memory buffer for the received data.

As soon as the data packet (or the error message) is available in the receive buffer, a LAM signal is generated (if enabled).

The communication line uses a simple $50\ \Omega$ coaxial cable as a physical medium.

The data transfer rate is 1 MBaud.

(A functional Block Diagram is shown in Fig. 1.1.)




Fig. 1.1: Mod. C117B Block Diagram

2. SPECIFICATIONS

2.1. PACKAGING

Single width CAMAC module.

2.2. EXTERNAL COMPONENTS

(Refer to Fig. 2.1).

CONNECTORS

- No. 1 "SERIAL LINE" LEMO 00 type, 50 Ω connector;
connector for the H.S. CAENET communication line.
The "DATA" LED is On when the H.S. CAENET Node is active.

DISPLAYS

- No.1 "DATA" red LED;
is On when the H.S. CAENET Node is active.

SWITCHES

- No.1 "RESET" push button; by pushing this button
the C117B enters in restart mode; this causes the following operations:
 - the buffers are cleared;
 - the LAM is cleared;
 - the LAM is disabled;
 - every data transfer is aborted;
 - the C117B does not accept any commands.

It remains in this status for about 3 msec.

2.3. POWER REQUIREMENTS

+ 6V 1.2 A




Fig. 2.1: Mod. C117B Front Panel

3. OPERATING MODES

3.1. H.S. CAENET NETWORK OPERATION

H.S. CAENET Network is a send and receive half duplex system; it permits asynchronous serial transmission of data packets along a simple 50Ω coaxial cable. Several devices (H.S. CAENET Nodes) are able to share the same media to transmit and receive data.

Each Node is able to receive the serial data packet and store it automatically in the RX FIFO and transmit the data contained in the TX FIFO (see Fig. 1.1). Both FIFOs are 512 byte deep.

The H.S. CAENET Node listens for clear coax before transmitting but it is not able to detect collisions on the cable; for this reason it is important to avoid line contention; i. e., the Nodes should not attempt to transmit at the same time.

Usually transfers between H.S. CAENET Nodes take place according to the typical MASTER/SLAVES communication: there is a single H.S. CAENET MASTER that initiates the transmission, all the SLAVES receive the data, and only the SLAVE addressed then accesses the serial line to transmit the data requested by the MASTER.

The maximum data packet length is 512 bytes.

An external clock source provides the basic time reference in the Node: the clock frequency is three times the data transfer rate. Actually the clock frequency used in the H.S. CAENET network is 3 MHz (1 MBaud transfer rate);

The Node is seen as an 8 bit peripheral composed of a collection of registers and two memory buffers arranged in FIFO logic. It generates an interrupt (H.S. CAENET interrupt) upon:

- the completion of a transmission of a data packet;
- the reception of a data packet;
- when the RX FIFO has been completely unloaded.

3.2. H.S. CAENET NODE OPERATION

The basic operation of the H.S. CAENET Node consists in 3 distinct modes:
Transmit, **Receive** and **Restart** mode.

- In the Transmit mode the Node accesses the data stored in the TX FIFO and transmits them on the cable.
- In the Receive mode the serial packet is stored in the RX FIFO.
- In Restart mode the Node does not execute any commands, all the TX and RX buffers are cleared and the H.S. CAENET interrupt is removed; it remains in this mode until it detects that the line is clear.

3.3. THE MOD. C117B H.S. CAENET CAMAC CONTROLLER

The Model C117B HIGH SPEED (H.S.)CAENET CAMAC CONTROLLER has been designed to easily control an H.S. CAENET network through the CAMAC bus. It houses an H.S. CAENET Node and a Control logic (microprocessor based with dedicated firmware) that integrates the functions of Node controller with Network error reporting and H.S. CAENET interrupt handler.

The Control logic directly controls the on-board H.S.CAENET Node. Its multiplexing logic interfaces the 16 WRITE and READ lines with the two 8 bit FIFOs so that they are seen by CAMAC as 16 bit wide buffers (Transmit and Receive Data Buffer).

It receives commands from any computer connected to CAMAC In such a way that few CAMAC Functions allow the User to easily control the serial communication on the H.S. CAENET network. The communication is performed according to the typical MASTER/SLAVE communication protocol, where the CAMAC Crate Controller assumes the H.S. CAENET MASTER function.

It is composed of a collection of registers, for the operation control, and two memory buffers for the transmitted and received data packets, arranged in a 16 bit FIFO 256 word deep (see Fig.1.1).

When the H.S. CAENET operation fails, the on-board Control logic generates error messages that are stored in the Receive Data Buffer.

As soon as the data packet (or the error message) is available in the Receive Data Buffer, a LAM signal is generated (if enabled).

3.4. MOD C117B OPERATING MODES

The following paragraphs describe the various operations that can be performed through CAMAC to accomplish an H.S. CAENET communication.

3.4.1. MOD C117B RESET

It is possible to reset the C117 B in these ways:

- by performing an F(9) N Function;
- by performing a C Command;
- by performing a Z Command;
- by pushing the Front Panel push button.

After one of these operations the C117B enters in Restart mode; this causes the following operations:

- the buffers are cleared;
- the LAM is cleared;
- the LAM is disabled;
- every data transfer is aborted;
- the C117B does not accept commands.

It remains in this status for about 3 msec.

3.4.2. DATA PACKET STORAGE

The data to be transmitted are stored in the Transmit Data Buffer by performing one or more F(16) N Functions with the data asserted on the WRITE lines W<1..16>.

The Q response to the F(16) N Function indicates whether the datum has been stored or not in the Transmit Data Buffer;

- Q=1: data has been stored in the Transmit Data Buffer
- Q=0: the Transmit Data Buffer is not available for data storage. This may happen in the following cases:
 - H.S. CAENET Node active (it is transmitting a previous data packet or it is receiving the SLAVE response data packet);
 - Transmit Data Buffer full (the maximum number of data stored is 256).

3.4.3. START TRANSMISSION

An F(17) N Function enables the Control logic to transmit on the cable the data packet stored in the Transmit data buffer.

The logic first check if the Buffer is empty,

- if not, the logic sets the H.S.CAENET Node in the Transmit mode and the data packet is transmitted on the cable.
- If the Buffer is empty the control logic does not activate the transmission and write into the Receive data buffer an error code (error %FFFD see Tab. 5.3).

The Q response indicates whether the Start Transmission command has been recognized or not by the Mod. C117B:

- Q=1 means that the Transmit command has been successfully recognized and that a valid response can be read in the Receive Data Buffer within a maximum period of 500 msec (SLAVE Response Time-out);
- Q=0 means that the H.S. CAENET Node is not able to transmit data. This may happen if the H.S. CAENET Node is active (it is transmitting a previous data packet or it is receiving the SLAVE response).

3.4.4. WAITING FOR THE SLAVE RESPONSE

The Control logic waits for the SLAVE Response for about 500 msec; if no data packet is received within this period, the Control logic stores an error code (error %FFFF see table 5.3) in the Receive Data Buffer.

If a data packet is received from the cable within the SLAVE Response Time-out, the Control logic checks if it has the correct header: if not, it first clears the Receive Data Buffer and then stores an error code in it (error % FFFE see table 5.3).

After these operations the Receive Data Buffer contains valid data (an error code or the SLAVE response) for the CAMAC Crate Controller that has initiated the H.S. CAENET Communication.

At this point the Control logic enables the CAMAC reading (Q=1 on F(0) N) and, if the LAM generation is enabled, a LAM signal is asserted on the CAMAC dataway.

3.4.5. READING THE RESPONSE

The User after the Transmission of the data packet expects a response in the Receive Data Buffer; the content of the Receive Data buffer is read by performing F(0) N Functions (the required data are present on the READ line R<1..16>).

The presence of valid data can be recognized in two different ways: in polling mode or by the LAM signal.

Polling mode:

- After the Start Transmission operation the User reads the content of the Receive Data Buffer by performing F(0) N Functions. The Q response indicates whether the data read is valid or not.
 - Q=1 means valid data;
 - Q=0 means no valid data.
- i.e. After the F(17) N Function the F(0) Function must be repeated until a Q=1 response is obtained

LAM signal

- The generation of the LAM signal means that valid data are present in the Receive Data Buffer

The readout is over when Q=0 (Q STOP readout operation).

The LAM is cleared whenever the last datum has been read.

3.4.6. ENABLE/DISABLE LAM GENERATION

It is possible to enable/disable the C117B LAM generation in the following way:

ENABLE by performing an F(26) N Function.

DISABLE by performing an F(24) N Function.

 by performing an F(9) N Function;

 by performing a C Command;

 by performing a Z Command;

 by pushing the Front Panel push button "RESET"

At power-on the LAM generation is disabled.

3.5. C117B-SLAVE COMMUNICATION SEQUENCE

The operations previously described are summarized in the following report:

- **write the data packet in the Transmit Data Buffer;** in the packet is contained the H.S. CAENET address of the SLAVE (see Tab 5.1 for the data structure).

for each data:

- perform an F(16) N Function
- if Q=1
 - {
the data is stored in the buffer.
}
- else
 - {
error.
}

- **Transmit the data packet:**

- perform an F(17) N Function
- if Q=1
 - {
the C117B H.S. CAENET Node enters in the Transmit mode and the data packet stored is transmitted on the cable.
}
- else
 - {
error
}

- **Wait for the SLAVE response**

- if LAM is enabled
 - {
wait for C117B LAM: when LAM is asserted go to the Read response section
}
- else
 - {
- perform an F(0) N Function
- if Q=0 discard the data and repeat the operation
- if Q=1 accept the data read: it may be the first data of the SLAVE response data packet or a Control Logic error message; go to the Read Response section
}

- **Read response**

- perform an F(0) N Function
- if Q=1 accept the data read and repeat the operation
- if Q=0 discard the data read and exit: the Receive Data Buffer is empty .

4. CAMAC FUNCTIONS

The standards CAMAC functions listed in Table 4.1 allow the User to perform the required control and setting operations on each SLAVE in the H.S. CAENET network.

X response is generated for all valid function.

Q response is generated for each valid function unless is otherwise specified.

Table 4.1: Mod. C117B CAMAC Functions

F(0) N	Reads the data stored in the Mod. C117B Receive Data buffer. Q response while the buffer contains data.
F(8) N	Tests the LAM line. Q response if LAM is true.
F(9) N	Resets the module (clears buffers and LAM, disables the LAM line, aborts data transfer).
F(16) N	Stores the data into the Mod. C117B Transmit Data buffer. Q response until the buffer is full (256 16-bit words).
F(17) N	The Transmit data buffer content is transmitted on the cable.
F(24) N	Disables the LAM line.
F(26) N	Enables the LAM line.
C, Z	Same as F(9) N.

4.1. F(16) N FUNCTION (Write Transmit Data Buffer)

The Transmit Data Buffer is the buffer that is loaded with the data packet to transmit, it is arranged in a FIFO logic 16 bit wide (the data packet transmitted is composed of 16 bit words as shown in Tab 5.1).

The data are stored in this buffer by performing one or more F(16) N Functions with the data to be written asserted on the WRITE lines W<1..16>.

The Q response to the F(16) N Function indicates if the datum has been stored or not in the Transmit Data Buffer;

- Q=1: the data has been stored in the Transmit Data Buffer
- Q=0: the Transmit Data Buffer is not available for data storage. This may happen in the following cases:
 - H.S. CAENET Node active (it is transmitting a previous data packet or it is receiving the SLAVE response data packet);
 - Transmit Data Buffer full (the maximum number of data stored is 256)

4.2. F(0) N FUNCTION (Read Receive Data Buffer)

The Receive Data Buffer is the buffer where the H.S. CAENET Node automatically stores the data packet received from the SLAVE, or, where The Control Logic stores the error codes (if the H.S. CAENET operation has failed). It is arranged in a FIFO logic 16 bit wide (the data packet received is composed of 16 bit words as shown in Tab 5.1). The data contained in the Receive Data buffer are read by performing F(0) N Functions.

The required data are present on the READ line R<1..16>.

The Q response indicates if the data read is valid or not.

- Q=1: valid data;
- Q=0: no valid data.

4.3. F(17) N FUNCTION (Start Transmission)

The F(17) N Function enables the C117B Control Logic to transmit on the cable the data stored in the Transmit Data Buffer. If this operation is performed with the Transmit Data Buffer empty, the Control logic stores an error message in the Receive Data Buffer (error FFFD see Table 5.3).

The Q response indicates if the Start Transmission command has been recognized or not by the Control Logic:

- Q=1 means that the Transmit command has been successfully recognized and that a valid response will be available in the Receive Data Buffer within a period of 500 msec (the C117B Control Logic waits up to 500 msec for the SLAVE response; If no data packet is received by this period it stores in the Receive Data Buffer the error code %FFFF, see Table 6.21).
- Q=0 means that the H.S CAENET Node is not able to transmit data. This may happen if the H.S. CAENET Node is active (it is transmitting a previous data packet or it is receiving the SLAVE response).

4.4. F(8) N (Test LAM Line)

The Q response to this CAMAC Function allows to test the LAM line:

- Q=1: LAM asserted
- Q=0: LAM not asserted

4.5. F(9) N, C, Z (Reset Module)

The CAMAC C and Z commands and the F(9) N Function cause the C117B to enter in Restart mode; this produces the following operations:

- the buffers are cleared;
- the LAM is cleared;
- the LAM is disabled;
- every data transfer is aborted;
- the C117B does not accept commands.

It remains in this status for about 3 msec.

4.6. F(24) N (Disable the LAM Generation)

This CAMAC Function disables the LAM generation; this means that, when the Control Logic enables the CAMAC reading (at the end of a data packet reception) the LAM signal will not be generated.

4.7. F(26) N (Enable the LAM Generation)

This CAMAC Function enables the LAM generation; this means that, when the Control Logic enables the CAMAC reading (at the end of a data packet reception) the LAM signal will be asserted.

This function must be performed after the Power-on or after a Reset operation (C, Z, F(9)N and the pressing of the Front Panel push button), because these operations disable the LAM generation.

5. C.A.E.N. COMMUNICATION PROTOCOL

5.1. H.S. CAENET NETWORK FOR REMOTING CONTROL

H.S. CAENET provides a unique way of remotely controlling "passive" electronic modules; modules that have not been designed for specific data acquisition purposes, and therefore have no access to any bus like CAMAC or VME.

NIM modules (Delay Units, Attenuators, Amplifiers, I/O registers) as well as H. V. Supplies have several parameters which need to be adjusted under computer control; many CAEN units house an H.S. CAENET Node inside the module that allows the possibility of linking several devices of different types and functionality with a central controller.

5.2. H.S. CAENET NETWORK IMPLEMENTATION: CAEN APPROACH

CAEN has developed a transmission protocol via H.S. CAENET line that permits the monitoring and control of many CAEN units from a single controller. This network has the following structure and protocol:

The transfers between H.S. CAENET Nodes take place according to the typical MASTER/SLAVEs communication:

- There is a single MASTER: H.S. CAENET Controller
- The SLAVEs are daisy chained on the network, and are identified by an address code (from 0 to 99); the address is usually selectable via thumb-wheel switch located on the Front panel of the module.
- the H.S. CAENET MASTER starts the transmission, all the SLAVEs receive the data, and only the addressed SLAVE then accesses the serial line to transmit the data requested by the MASTER.

In this way is possible from a single point it to control up to 100 SLAVEs.

5.3. MASTER TO SLAVE DATA COMPOSITION

The MASTER-to-SLAVE data have to be written into the Transmit Data buffer by performing subsequent F(16) N functions as follows:

Table 5.1: MASTER to SLAVE Data Composition

Order	CAMAC Function	W16 to W1 (HEX)	Meaning
1	F(16) N	%0001	H. S. CAENET Controller identified code
2	F(16) N	%00XX	Crate Number
3	F(16) N	Code	Code of the operation to be performed
4 to 256	F(16) N	Set	Eventual set values

In the C117 B Receive Data Buffer the User reads the SLAVE response or a C117B error message (for example if the C117 B does not receive any SLAVE response within a period of 500 msec it stores the code %FFFF in the Buffer; see Tab. 5.3).

5.4. SLAVE TO MASTER DATA COMPOSITION

The answer data coming from the SLAVE or a Control Logic error message is stored into the C117B Receive Data buffer. The User can get it by performing subsequent F(0) N Functions. The following Table shows the structure of the SLAVE data packet:

Table 5.2: SLAVE to MASTER Data Composition

Order	CAMAC Function	Datum	Meaning
1	F(0) N	Error Code	Error code
2 to 255(*)	F(0) N	value	Eventual Parameter value

(*) The first data of the packet is read and checked by the Control Logic as shown in §3.4.4.

The Error codes are described in Tab. 5.3.

5.5. ERROR CODES DESCRIPTION

The Error codes are described in the following Table:

Table 5.3: Error Codes

Datum (Hex)	Meaning
%0	Successful operation. SLAVE message.
%FFFD	No data to be transmitted; it has tried to start a transmission with the Transmit data Buffer empty (Control logic error message).
%FFFE	The H.S. CAENET Controller identifier is incorrect (Control Logic error message).
%FFFF	The addressed SLAVE does not exist. This message are generated after a period of 500 msec (Control Logic error message).

All the other possible error codes from the SLAVE module have the format "%FFnn" where "nn" can be any number.

APPENDIX A: SOFTWARE BUGS AS OF SEPT. 1992

This appendix contains the software bugs recognized as of September 1992.

If one of the SLAVE in the H.S. CAENET Network has the address code = 0 the Network communications do not work.

Do not use SLAVE address code = 0.

APPENDIX B: ELECTRICAL DIAGRAMS

APPENDIX C: COMPONENT LIST AND LOCATIONS